

# Donner BASKET

**Dřezová výpust s nerezovou mřížkou a košíkem ø 114 mm (otvor dřezu 90mm)  
se závitem 6/4"**



EAN: 8596220010506

**549 Kč**

454 Kč bez DPH

With a sink basket, you can peel vegetables and fruit directly in the sink, while also eliminating problems with a clogged siphon. Ideal for households, smaller catering operations, and for anyone who does not want or cannot purchase a waste disposer for various reasons. The set consists of a drain, a deep sink basket, a sieve, and a stainless-steel plug.

## **NEVER CLOGGED WASTE AGAIN**

During normal use of a kitchen or utility sink, the pipes can get clogged after some time. This is partly addressed by a small additional sieve in the sink, but when there is a larger amount of debris, it quickly gets filled up and the water stops draining. The waste collector in the drain combines a regular small sieve with a high-capacity basket, which prevents the waste from getting blocked.

## **HOW TO USE A SHOPPING CART?**

The drain can be closed at any time with a stainless steel plug, completely preventing water from draining from the sink. The plug is recessed in the sink plane. During normal use, the drain is covered by a small sieve. Whenever you want to use the large capacity basket, simply remove the sieve. With the deep sink basket, you can peel potatoes and vegetables directly into the sink. After completing work in the sink, the sieve is pulled out by two fingers using the wire handle. The sieve can be emptied into a waste bin or organic waste can be placed in a compost. The sink basket can be washed in a dishwasher.

## **QUALITY MATERIALS**

The lid, strainer, and basket are made of stainless steel with a chrome and nickel alloy. Thanks to this, they are highly resistant to corrosion and will serve you well for a long time. The plug is equipped with a high-quality silicone seal. The body of the drain is made of safe polypropylene. This plastic is known for its excellent chemical and mechanical resistance.

## **INSTALLATION**

The handy household handyman can handle the replacement of the existing drain for a drain with a basket within 15 minutes according to the attached instructions. With a standard siphon, the recommended minimum distance from the bottom of the sink to the center of the waste pipe in the wall is 17 cm. In the case of installation with a connection of the sink overflow to the siphon branch, or with the use of an overflow set, the recommended minimum distance is 24 cm.

## **Universal use**

Donner BASKET is not intended for households only. It is useful in catering establishments with large stainless steel washing tables and sinks. It is also used in hairdressing wash boxes, drainage channels for capturing dirt, etc.

**Note:** We recommend purchasing a [drainage set](#) for connection to the sink.

**!!! IT IS NOT POSSIBLE TO USE AQUASANITA AND GRANISIL BRANDS IN THE SINKS!!!**

It is not possible to place Reginox Modena and Reginox Belfast in the sink.

*Ceramic sinks with double bottom and integrated overflow can be attached up to a maximum thickness of 3 cm.*

## **Parts of the packaging:**

- Assembly instructions

# Parameters

## Basic parameters:

Model:	Donner BASKET
Use:	Universal (Households, catering establishments, hair salons...)
Warranty:	2 years
Product TARIC code:	73072980

## Technical parameters

Method of fastening/Installation:	Tightening with a center screw.
Sink flange material:	Stainless steel
Cover material/shell:	Non-toxic polypropylene
Basket material, plugs, nets:	Stainless steel
Basket volume:	250 ml
Discharge volume:	560 ml
Depth of the drain:	100
Maximum sink thickness:	3 cm

## Dimensions, weight, packaging

Dimensions width (cm):	114x144 mm (H/W)
Weight including packaging (kg):	0.6
Width of the packaging (cm):	12
Height of packaging (cm):	16
Depth of packaging (cm):	12



### DOWER BASKET

#### Návod

Instalácia  
Typová a ďalšia inštalácia sú uvedené v príručnici, ktorá sa nachádza vo vnútri balenia.

Príslušenstvo a doplnkové príslušenstvo  
Ak chcete zmeniť filter, použite príslušenstvo.

Očistenie a údržba  
Pravidelne čistujte filter a zvyšky potravinových odpadkov odstráňte.

Upozornenie  
Pri výmene filteru používajte príslušenstvo, ktoré je súčasťou balenia.

Upozornenie  
Pri výmene filteru používajte príslušenstvo, ktoré je súčasťou balenia.



